

CODE ASCII sur 7 bits

Binaire									b6	0	0	0	0	1	1	1	1
									b5	0	0	1	1	0	0	1	1
									b4	0	1	0	1	0	1	0	1
				Hexadécimal					0	1	2	3	4	5	6	7	
b3	b2	b1	b0	Décimal					0	16	32	48	64	80	96	112	
0	0	0	0	0	+0	NUL	TC7 (DEL)	SP	0	@	P	.	p				
0	0	0	1	1	+1	TC1 (SOH)	DC1	!	1	A	Q	a	q				
0	0	1	0	2	+2	TC2 (STX)	DC2	"	2	B	R	b	r				
0	0	1	1	3	+3	TC3 (ETX)	DC3	#	3	C	S	c	s				
0	1	0	0	4	+4	TC4 (BOT)	DC4	\$	4	D	T	d	t				
0	1	0	1	5	+5	TC5 (ENO)	TC8 (NAK)	%	5	E	U	e	u				
0	1	1	0	6	+6	TC6 (ACX)	TC9 (SYN)	&	6	F	V	f	v				
0	1	1	1	7	+7	BEL	TC10 (ETB)	'	7	G	W	g	w				
1	0	0	0	8	+8	FE0 (BS)	CAN	(8	H	X	h	x				
1	0	0	1	9	+9	FE1 (HT)	EM)	9	I	Y	i	y				
1	0	1	0	A	+10	FE2 (LF)	SUB	*	:	J	Z	j	z				
1	0	1	1	B	+11	FE3 (VT)	ESC	+	;	K	[k	é				
1	1	0	0	C	+12	FE4 (FF)	IS4 (FS)	,	<	L	\	l	ù				
1	1	0	1	D	+13	FE5 (CR)	IS3 (GS)	-	=	M]	m	è				
1	1	1	0	E	+14	SO	IS2 (RS)	.	>	N	^	n	-				
1	1	1	1	F	+15	SI	IS1 (US)	/	?	O	_	o	DEL				